



FILLER PLUS

instructions

WATER-BASED BINDING RESIN FOR FILLING WOODEN FLOORS

PREPARING THE BASE Ensure all flooring elements are firmly secured to the surface. Sand the flooring to be treated carefully to obtain a surface free from oil, grease and wax.

APPLICATION Allow the product to reach room temperature before use. The product should be mixed in a 1:1 ratio approximately, to obtain a homogeneous paste with fine dust obtained by sanding the base being treated. Spread the product with a smooth stainless steel plastering trowel, applying the paste to the gaps, or preferably applying a complete layer to the flooring. Repeat this step several times if necessary. Once dry (approximately 1 - 2 hours under normal conditions), sand with fine abrasive paper, removing dry product residue completely. Always check that wood moisture is between 8% to 12%, and that the ambient temperature is between 15°C to 25°C and relative humidity not above 75%. Always use adequate individual protection devices. Always consult the technical and safety data sheet for the product.

NOTE Failing to remove excess bonding product may lead to floor colour changes after varnishing. Given the large variety of wood types on the market, it is always advisable to carry out a test to check for colour changes in the wood being treated.