



STONE

instructions

SINGLE-COMPONENT NATURAL FINISH POLYURETHANE VARNISH

PREPARING THE BASE The wood flooring must be smoothed, filled and sanded thoroughly, and free from loose fragments such as oil, wax and silicone. The surface to be finished must be dry, with 8-12% moisture content. Ambient temperature between 15 and 25°C, relative humidity no greater than 75%. After sanding with 120/150 grit, vacuum the whole surface and then clean with an anti-static cloth.

APPLICATION Bring up to room temperature and shake carefully before use. Wait approximately 10–15 minutes, filter the product and apply an even coat using a roller or brush.

Always consult the product data sheet to ensure compatibility of the painting cycles.